



ASSEMBLY GUIDE

A comprehensive guide to:

- Display Assembly
 - Parts
- Shipping Supplies
- Supplemental Materials

Spinner 4 Panel Display

SPINNER 4 PANEL DISPLAY

ITEM NO. 907

PARTS INCLUDED: (1) Base; (1) Bottom Tube; (1) Middle Tube; (1) Top Tube; (1) Bottom Wire Frame; (1) Top Wire Frame; (2) Bearings; (4) Casters; (1) Wrench

STEP 1

Screw the casters into the bottom of the base foot, tighten with wrench provided




STEP 2

Insert bearing #1 onto the base tube




STEP 3

Insert bottom tube into base




STEP 4

Place bottom wire frame onto bottom tube, resting on bottom bearing, noting rack orientation




STEP 5

Insert middle tube into bottom tube




STEP 6

Insert middle tube into bottom tube




STEP 7

Slide bearing #2 onto top tube, resting on lip




STEP 9

Insert rounded prongs on top wire frame into slots on back of blue cardboard display




STEP 8

Place top wire rack onto top tube, resting on top bearing, noting rack orientation



STEP 10

Slide bottom of cardboard display into slot on bottom wire rack



Attached panel should look as shown below




Example of completed 4-Panel Cardboard Spinner Display with headers and product



907 SQUARE RACK SPINNER


ASSEMBLY INSTRUCTIONS

PARTS LIST




ASSEMBLY


1




2



3



4



Display is complete.